



# Asynchronous Serial Device Driver for OS/2

For use with OS/2 2.11 or later

## User's Manual

QUATECH, INC.  
5675 Hudson Industrial Parkway  
Hudson, Ohio 44236

TEL: (330) 655-9000  
FAX: (330) 655-9010  
<http://www.quatech.com>

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Features	1
1.2	Supported Serial Port Adapters	2
1.3	Requirements	2
1.4	Driver Components	2
<b>2</b>	<b>Installation</b>	<b>3</b>
2.1	Preparation	3
2.2	Install the Files and Add Configurations	4
2.3	QCOM.SYS Parameters	4
2.3.1	Quatech PCI Serial Port Adapters	5
2.3.2	Quatech PCMCIA Serial Port Adapters	8
2.3.3	Third-party PCMCIA Cards	8
2.3.4	All other serial ports	9
2.4	QVCOM.SYS Parameters (Address/IRQ Masquerading)	10
2.4.1	Important considerations when using masquerading	10
2.5	Optional Features	11
2.5.1	Installed port listing ("/L")	11
2.5.2	Assert Break on Init ("/B")	11
2.5.3	Create Boot Log File ("/D")	11
2.5.4	Fast RTS Toggle-On-Transmit ("/FT")	12
2.6	Overall Configuration Example	12
<b>3</b>	<b>Using The Driver</b>	<b>13</b>
3.1	OS/2 Application Software	13
3.2	Win-OS/2 Application Software	13
3.3	DOS Application Software	13
3.3.1	DOS INT14h support	13
3.3.2	DOS Properties	14
3.4	Interrupt Sharing	14
3.4.1	PCI bus	14
3.4.2	PCMCIA bus	15
3.4.3	ISA bus	15
3.5	Baud Rates	15
3.5.1	High baud rates (> 57,600 bps)	15
3.6	PCMCIA "Hot-Swapping"	16
3.7	Hardware Manager	16
3.8	Limitations	18
<b>4</b>	<b>Troubleshooting</b>	<b>19</b>

© 1993-2006 Quatech, Inc.

## NOTICE

The information contained in this document cannot be reproduced in any form without the written consent of Quatech, Inc. Likewise, any software programs that might accompany this document can be used only in accordance with any license agreement(s) between the purchaser and Quatech, Inc. Quatech, Inc. reserves the right to change this documentation or the product to which it refers at any time and without notice.

The authors have taken due care in the preparation of this document and every attempt has been made to ensure its accuracy and completeness. In no event will Quatech, Inc. be liable for damages of any kind, incidental or consequential, in regard to or arising out of the performance or form of the materials presented in this document or any software programs that might accompany this document.

Quatech, Inc. encourages feedback about this document. Please send any written comments to the Technical Support department at the address listed on the cover page of this document.

DOS and Windows are trademarks or registered trademarks of Microsoft Corporation. OS/2 is a registered trademark of IBM Corporation. Any other trademarks or registered trademarks are property of their respective owners.

# 1 Introduction

---

The Quatech Asynchronous Serial Device Driver Set for OS/2 is a software package which enhances the serial communications capabilities of personal computers using the IBM OS/2 operating system, version 2.11 or higher.

## 1.1 Features

- { Support for up to 32 COM ports
- { Compatible with all standard serial ports
- { Full Plug-and-Play support for Quatech PCI serial port adapters, including interrupt sharing between them
- { Support for PCMCIA serial ports
- { Quatech intelligent serial port adapters supported
- { Support for the FIFO modes of 16550 and 16750 UARTs
- { Serial port bit rates up to 921,600 bits per second with 16750 UARTs
- { Support for OS/2, DOS, and Windows sessions under OS/2
- { Address and IRQ masquerading for DOS and Windows sessions
- { Drop-in replacement for IBM's standard OS/2 serial port device drivers, including installation syntax

## 1.2 Supported Serial Port Adapters

- { All Quatech serial adapters
- { Standard (legacy) single serial port hardware such as built-in motherboard ports.
- { Multiport serial adapters from manufacturers other than Quatech are not supported.

Performance is enhanced by the interrupt status register found on Quatech PCI and PCMCIA serial adapters.

## 1.3 Requirements

- { OS/2 version 2.11 or later (earlier versions do not support PCI devices)
- { Approximately 50 kB of hard drive space
- { The Interrupt Status Register on Quatech serial adapters must be enabled

## 1.4 Driver Components

- { QCOM.SYS physical device driver (replaces IBM's COM.SYS)
- { QVCOM.SYS virtual device driver for DOS support (replaces IBM's VCOM.SYS)

## 2 Installation

---

This device driver set is designed to be a direct replacement for software modules supplied by IBM in the OS/2 product. Installation is simple, and changes needed in other portions of a currently working system are minimal. A system backup is suggested before installation.

If "Serial Device Support" was not selected during OS/2 installation or a subsequent Selective Install, the IBM drivers may not be present on the hard drive. This will not affect installation of the Quatech drivers.

### 2.1 Preparation

- Will Quatech PCI serial ports be used?  
If yes, ensure that the jumpers labeled "X2", "X4", "X8" and "SPAD" are removed or are installed in neutral (spare) positions. **Removing the "SPAD" jumper enables the interrupt status register.**
- Will Quatech PCMCIA serial ports be used?  
If yes, ensure that the appropriate Quatech OS/2 PCMCIA Client Driver device driver has been installed according to the documentation that accompanied those drivers. The client driver should be listed in the CONFIG.SYS file below the QCOM.SYS device driver.
- Will built-in motherboard (chipset) serial ports be used?  
If yes, record the adapter's base address and IRQ.

- Will other serial ports made by manufacturers other than Quatech be used?  
Quatech's device drivers will operate any serial port that appears to be a standard (legacy) serial port. For these ports, record the port's base address and IRQ. Quatech's device drivers will not operate third-party multiport serial adapters.

## 2.2 Install the Files and Add Configurations

1. Copy QCOM.SYS from the installation disk to the \OS2 directory on the boot partition. Copy QVCOM.SYS from the installation disk to the \OS2\MDOS directory on the boot partition. These locations are suggestions; you may elect to use other directories if you like. Do NOT delete the IBM device driver files.
2. Edit the boot partition's CONFIG.SYS. Comment out entries for COM.SYS and VCOM.SYS, if present, by inserting "REM " at the start of the line. Immediately following these commented-out entries, or at the end of the CONFIG.SYS file, add entries for the Quatech device drivers:  
**DEVICE=d:\path\QCOM.SYS (parameters) ... (parameters)**  
**DEVICE=d:\path\QVCOM.SYS (parameters)** where  
 "d:\path" indicates the drive and directory path where the Quatech drivers were copied.  
 Parameters are discussed below.
3. Save the edited CONFIG.SYS, shutdown the system and reboot.

## 2.3 QCOM.SYS Parameters

The basic parameters for QCOM.SYS are the same as those for IBM's COM.SYS. Extra optional parameters have been added for Quatech adapters. All parameters are case-insensitive, and do not include the quote marks in the descriptions. Parameters not marked optional are mandatory.

All parameter sets must be enclosed by a pair of parentheses. Global options must reside outside of any pair of parentheses. There should be no spaces within a pair of parentheses. There must be at least one space separating each set of parameters.

The format for the parameters depends on the type of serial port being installed. A set of parameters is needed for each device, with Quatech multiport adapters counting as one device. Parameter formats are discussed below.

### 2.3.1 Quatech PCI Serial Port Adapters

Parameter format: (id,port,flags)

**id Quatech adapter ID**

This field corresponds to the product name, and should contain one of the following:

"DSC-100"	for Quatech DSC-100 two-port PCI adapter
"DSC-200/300"	for Quatech DSC-200/300 two-port PCI adapter
"QSC-100"	for Quatech QSC-100 four-port PCI adapter
"QSC-200/300"	for Quatech QSC-200/300 four-port PCI adapter
"ESC-100D"	for Quatech ESC-100D eight-port PCI adapter
"ESC-100M"	for Quatech ESC-100M eight-port PCI adapter
"SSCLP-100"	for Quatech SSCLP-100 one-port low-profile PCI adapter
"SSCLP-200/300"	for Quatech SSCLP-200/300 one-port low-profile PCI adapter
"DSCLP-100"	for Quatech DSCLP-100 two-port low-profile PCI adapter
"DSCLP-200/300"	for Quatech DSCLP-200/300 two-port low-profile PCI adapter
"QSCLP-100"	for Quatech QSCLP-100 four-port low-profile PCI adapter
"QSCLP-200/300"	for Quatech QSCLP-200/300 four-port low-profile PCI adapter
"ESCLP-100"	for Quatech ESCLP-100 eight-port low-profile PCI adapter

**port Starting port number, 1 or 2 decimal digits**

The first port on the adapter. The other ports on the adapter follow in contiguous sequence. For example, to install a Quatech QSC-100 four-port adapter for COM9 through COM12, use "9" or "09".

**flags Option flags (OPTIONAL --- Use only if needed)**

Flags may be placed in any order, separated by commas. Some are mutually exclusive, in which case the right-most flag will be the one used.

Consecutive spurious interrupt control (mutually exclusive):

"D" = Disable port after 1000 (default), "I" = Ignore, "P" = Post to application

UART selection override control (mutually exclusive):

"F5" = Limit to 16550 mode (16-byte FIFOs)

"F4" = Limit to 16450 mode (no FIFOs)

The driver defaults to 16450 mode and automatically detects a 16550 or 16750 if present. The override should be used only if the user wishes to limit the FIFO size.

"O" = Make this PCI adapter optional. If the PCI adapter is not installed in the computer at boot time, the driver will display a warning message and continue to load. This option flag is supported only for PCI devices.

"OQ" = "Quiet" version of "O" option. The warning message is not displayed on the screen, but will be written to the log file if the /D option is used (see section 2.5).

**Example: (QSC-100,7)**

A Quatech QSC-100 four-port PCI adapter providing COM7 through COM10 is installed. The base address and IRQ used by the board are automatically assigned by the system and detected by the device driver.

### 2.3.2 Quatech PCMCIA Serial Port Adapters

Do not place parameters on the QCOM.SYS command line for these products. The client device drivers take parameters for PCMCIA serial ports. See the client driver documentation for details.



### **2.3.3 Third-party PCMCIA Cards**

Single-port serial cards and client drivers from other manufacturers may be supported if their client drivers are written to communicate with IBM's standard COM.SYS serial port device driver. The QCOM.SYS uses a superset of the client driver interface used by COM.SYS.

### 2.3.4 Motherboard serial ports

Parameter format: (port,io,irq,flags)

**port Port number, 1 or 2 decimal digits**

The port number. For example, to install a COM9, use "9" or "09".

**io Base I/O address, 3 or 4 hex digits**

The base I/O address for the serial port. For example, to install an internal modem at 3e8 hex, use "3e8" or "03e8". This value must match the port's hardware address settings.

**irq Interrupt (IRQ) level, 1 or 2 decimal digits**

The hardware interrupt level (2-15) used by the serial port.

**flags Option flags (OPTIONAL --- Use only if needed)**

Flags may be placed in any order, separated by commas. Some are mutually exclusive, in which case the right-most flag will be the one used.

Consecutive spurious interrupt control (mutually exclusive):

"D" = Disable port after 1000 (default), "I" = Ignore, "P" = Post to application

UART selection override control (mutually exclusive):

"F5" = Limit to 16550 mode (16-byte FIFOs)

"F4" = Limit to 16450 mode (no FIFOs)

The driver defaults to 16450 mode and automatically detects a 16550 or 16750 if present. The override should be used only if the user wishes to limit the FIFO size.

**Example:** (1,3F8,4)

This is a standard motherboard serial port. It is installed as COM1 at the standard base address 3F8 hex on the standard IRQ4.

## 2.4 QVCOM.SYS Parameters (Address/IRQ Masquerading)

The QVCOM.SYS device driver virtualizes the base address and interrupt level (IRQ) for serial ports accessed in a DOS or Windows session. In cases where DOS or Windows software cannot properly handle the actual hardware settings, the virtual driver can pretend that the serial port is installed using other values. This is called "Address/IRQ Masquerading."

This feature can be especially useful in trying to use legacy DOS or Windows software with PCI serial ports. To use it, simply add the proper parameters to the QVCOM.SYS line in the CONFIG.SYS file and reboot the computer. There is no option for screen output of the virtual device driver's configuration, so great care should be taken in exercising this option.

### 2.4.1 Important considerations when using masquerading

- { When a serial port is masquerading, it is still available to OS/2 applications using the "COMx" port name.
- { DOS and Windows applications using the port must not attempt to use the actual hardware settings to access the port.
- { The address and IRQ to be used for the make-believe values can not be used by other hardware.
- { It is not possible to change the port number ("COMx" port name).

Parameter format: (port,io,irq)

**port Port number, 1 or 2 decimal digits**

The actual port number. For example, for COM3, use "3" or "03".

**io Base I/O address, 3 or 4 hex digits**

The base I/O address where the serial port will pretend to reside. For example, to masquerade at 3e8 hex, use "3e8" or "03e8". This address range should not be used by any other hardware in the system.

**irq Interrupt (IRQ) level, 1 or 2 decimal digits**

The hardware interrupt level (2-15) the serial port will pretend to use. This IRQ should not be used by any other hardware in the system.

**Example:** (5,3F8,4)

Force COM5, regardless of its actual hardware settings, to appear as a standard COM1 at base address 3F8 hex and IRQ4 to all DOS and Windows programs. OS/2 programs can still access the port as "COM5."

## 2.5 Optional Features

The device driver supports some optional features. These features are enabled by adding an option switch to the QCOM.SYS command line. The option switch may be placed anywhere on the line outside of parameter groups in parentheses, and it affects all serial ports.

**Example:**     DEVICE=d:\os2\qcom.sys (QSC-100,4) /L /B /D /FT

### 2.5.1 Installed port listing ("/L")

This option causes the QCOM.SYS device driver to print a list of the serial ports it has installed during boot time. The COM port name, base address, IRQ and detected UART type are listed. If the serial port resides on a Quatech multiport serial adapter, the bus type and adapter name are shown as well. PCMCIA serial ports are not listed.

For PCI adapters, the address and IRQ values shown are those assigned by the PCI BIOS. For all other adapters, the values shown are those supplied by the user on the QCOM.SYS command line. This display can be used to reveal the configuration of PCI adapters and to verify which serial ports the device driver is actually controlling.

The device driver pauses five seconds after completing the display to allow the user time to read the information listed.

### 2.5.2 Assert Break on Init ("/B")

This option causes the QCOM.SYS device driver to momentarily (1/4 second) assert and then deassert a serial BREAK condition and the RTS and DTR signals on each port during initialization. This can sometimes be helpful in resetting external devices that are in an indeterminate state at boot time.

### 2.5.3 Create Boot Log File ("/D")

This option causes the QCOM.SYS device driver to create a file named QCOM.LOG in the root directory of the boot drive. This file will contain a copy of each message displayed by the driver during its boot-time initialization. The driver uses ANSI escape sequences to generate the different colors used in some boot messages (errors and warnings are red, for example). These ANSI escape sequences will appear as "junk" if this file is viewed with a text editor. To view the file clearly, use the TYPE command at an OS/2 command prompt. (Example: C:>TYPE QCOM.LOG)

The /D option automatically activates the /L option.

## 2.5.4 Fast RTS Toggle-On-Transmit ('/FT')

The /FT option causes the QCOM.SYS device driver to aggressively process the RTS toggle-on-transmit protocol used in two-wire half-duplex environments. RTS will be deasserted approximately one bit-time following the end of transmitted data. Without this option, the driver may take up to 32 milliseconds to deassert RTS.

## 2.6 Overall Configuration Example

```
DEVICE=D:\OS2\QCOM.SYS (1,03F8,4) (3,3E8,15) (QSC-100,4) /L
DEVICE=D:\OS2\MDOS\QVCOM.SYS (4,2E8,3)
```

- { The Quatech drivers are installed in the suggested locations on a Drive D:.
- { COM1 is installed at the standard base address 3F8 hex and standard IRQ4.
- { COM2 is used by a serial mouse. MOUSE.SYS controls this port, so it is not specified for QCOM.SYS.
- { COM3 resides at the typical address for COM3, 3E8 hex, but uses IRQ15.
- { A Quatech QSC-100 PCI four-port PCI adapter supplies COM4 through COM7.
- { A listing of installed COM ports will be displayed at boot time.
- { QVCOM.SYS is providing DOS and Win-OS/2 virtual serial port support.
- { COM4, on the QSC-100, is masquerading as a standard COM4 at base address 2E8 hex and IRQ3 for DOS and Windows sessions.

## 3 Using The Driver

---

The drivers can service up to 32 serial ports. The names of these ports range from "COM1" to "COM32".

### 3.1 OS/2 Application Software

An OS/2 application can access any installed serial port from COM1 through COM32 by specifying the "COMxx" name.

### 3.2 WIN-OS/2 Application Software

The Windows environment must be informed of the serial port configuration via the "Ports" icon in the Windows Control Panel. Use the "/L" port listing option or check in Hardware Manager (see page 14) to find the base address and IRQ of each installed serial port, then plug those values into Control Panel. Due to limitations in the Windows environment itself, Win-OS/2 sessions are limited to the use of COM1 through COM4. COM5 through COM32 cannot be used by a Windows application.

### 3.3 DOS Application Software

A DOS application can access any installed serial port, COM1 through COM32. DOS applications normally need to be configured with the base address and IRQ level for the particular serial port because DOS applications typically do direct access to the hardware. Even when a DOS application indicates that it is using "COM1", for example, the application is actually making an assumption as to the hardware configuration. Use the "/L" port listing option or check in Hardware Manager (see page 14) to find the base address and IRQ of each installed serial port, then plug those values into the DOS application.

QVCOM.SYS provides the DOS session with an emulation, or virtualization, of a 16550 UART. All of the virtual 16550's registers are available for read or write accesses by DOS applications. This 16550 emulation holds true even if the actual port in use is equipped with a 16450 UART.

#### 3.3.1 DOS INT14H support

QVCOM.SYS provides full support for the Interrupt 14 hex serial port BIOS interface. In fact, this interface has been extended to support up to 32 serial ports. To access a serial port using BIOS Interrupt 14 hex, the port number is placed in the DX register. Normally, this interface is limited to four serial ports, COM1, COM2, COM3, and COM4, represented by 0, 1, 2, and 3, respectively, in the DX register.

QVCOM.SYS intercepts Interrupt 14 hex accesses and allows any installed port to be used. Serial ports beyond COM4 are accessed simply by extending the number sequence above. For example, use DX=4 to access COM5, or DX=31 (decimal) to access COM32.

### 3.3.2 DOS Properties

QVCOM.SYS provides most of the same DOS settings as IBM's VCOM.SYS. For full details on these settings, consult the OS/2 documentation or online help. Differences between the Quatech and IBM drivers are discussed here. It is suggested that these DOS settings be left at their default values unless necessary.

#### COM\_DIRECT\_ACCESS

This setting is ignored (considered OFF) for ports on Quatech non-intelligent multiport adapters using an interrupt status register and for ports on Quatech intelligent multiport adapters. Bypass of the driver would prevent proper servicing of the adapter. **Do not attempt to use this setting with COM ports using address/IRQ masquerading!**

#### COM\_SELECT

This setting has been expanded to allow any port from COM1 to COM32 to be selected. "ALL" and "NONE" are also supported.

#### COM\_HOLD

No changes.

#### COM\_RECEIVE\_BUFFER\_FLUSH

The IBM OS/2 2.1 release included this new DOS session setting in VCOM.SYS. The Quatech QVCOM.SYS driver does not implement this DOS setting.

## 3.4 Interrupt Sharing

The device driver generally supports sharing of interrupts for serial ports adapters operating in hardware environments "friendly" to shared interrupts.

### 3.4.1 PCI bus

PCI bus computers inherently support the sharing of hardware interrupts. The device driver requires that the interrupt status register be enabled. Interrupts are shared by all of the serial ports on a given adapter. Interrupts can also be shared by multiple adapters.

### 3.4.2 PCMCIA bus

Quatech multiport PCMCIA serial port cards will share a single interrupt between all ports on the card. Interrupt sharing between multiple PCMCIA cards is governed by the PCMCIA subsystem, and is not supported by this device driver.

## 3.5 Baud Rates

All standard baud rates up to 115,200 bits per second are supported for all UART types. If 16550 UARTs are detected on a Quatech Enhanced Serial Adapter, the maximum baud rate increases to 230,400 bits per second. If 16750 UARTs are detected on a Quatech Enhanced Serial Adapter, the maximum baud rate increases to 921,600 bits per second. Actual performance may be limited by the computer's hardware configuration (CPU speed, free memory, etc.), cable quality and length, and system software loading amongst other factors.

The driver will refuse to set any baud rate that the hardware cannot achieve within 0.01%, with the exception of 110 and 2000 bits per second.

### 3.5.1 High baud rates (> 57,600 bps)

The device driver implements the async IOCTL 0x43 and 0x63 functions for support of high baud rates. This is the only way for software to set baud rates above 57,600 bps. The async IOCTL 0x41 and 0x61 functions reject baud rates higher than 57,600.

Quatech Enhanced Serial Adapters use jumper-selectable UART clock input rates. The factory shipping configuration is a software-programmable mode defaulting to a standard times-one clock, signified by having the "X2", "X4" and "X8" jumpers removed (there may be spares installed in neutral positions).

For baud rates higher than 115,200 bps, the device driver uses the clock rate multiplier logic found on Quatech Enhanced Serial Adapters. If none of the rate selector jumpers are applied (see your hardware manual), the driver can set baud rates as high as 230,400 bps for 16550 UARTs or 921,600 bps for 16750 UARTs. Software may set these baud rates directly by using the appropriate OS/2 function calls (IOCTL functions 0x43 and 0x63 for baud rates higher than 57,600).

If a rate selector jumper is applied, the device driver will accept only baud rates up to 115,200 bps. The hardware will multiply the baud rate in accordance with the jumper setting without the device driver's knowledge. For instance, if the "X2" jumper is applied and software is set for 115,200 bps, the actual baud rate will be 230,400 bps.

Applying a rate select jumper to force higher baud rates can be useful if a particular software program does not support the higher rates. Note that the jumper selection affects all ports on the adapter.

## 3.6 PCMCIA "Hot-Swapping"

The QCOM.SYS driver is notified when a Quatech PCMCIA serial port card is inserted or removed. OS/2 sessions will be updated with the new information immediately. DOS and Windows



sessions will not receive new PCMCIA port information (either insertions or removals). DOS and Windows sessions started AFTER the insertion or removal will have the new information.

Avoid removing PCMCIA cards while they are being accessed by a program! Doing so can create undesirable results!

### **3.7 Hardware Manager**

The device driver is fully compliant with the Resource Manager component in OS/2 Warp. All resources required by serial ports controlled by the driver are reported to the system. The user can examine the resources used by installed serial ports by opening the Hardware Manager object.

To open Hardware Manager, click the right mouse button on an open area of the desktop and select System Setup. Alternatively, System Setup can be found in the OS/2 System folder. Double-click on Hardware Manager.

Serial port icons in Hardware Manager have titles starting with "SERIAL". Quatech's device driver enhances the display by adding the logical COM port name and an indication of whether the port is contained on a Quatech PCI adapter or is a standard legacy port. The base address and IRQ values shown can be plugged into DOS and Windows software to allow access to the serial ports from those programs.

PCMCIA serial ports do not benefit from the display enhancements. The reporting for them is done by the PCMCIA subsystem of OS/2.

### **3.8 Limitations**

1. Performance is dependent on the computer system in which the software is used. In general, more powerful systems and systems with lighter process loads can accommodate the highest cumulative data throughput.
2. DMA serial ports are used only as standard interrupt-driven ports.
3. The OS/2 and DOS session MODE commands are not capable of working with ports COM10 through COM32.

## 4 Troubleshooting

---

Listed below are some tips that can be consulted in the event of difficulties. Consulting this information may make calling for technical support unnecessary.

- { Ensure that the Interrupt Status Register on a Quatech serial adapter is enabled. All products ship from our factory with this register enabled. This is done using a jumper on some PCI adapters. PCMCIA adapters will have this register enabled unless you have disabled it with a command line option on the adapter's PCMCIA client device driver. Refer to the User's Manual that came with your serial adapter for details on how to check the Interrupt Status Register setting and enable it if necessary.
- { Any ports that cannot be installed will cause a failure message for that particular port to be displayed during system boot. Other ports will still operate. Such a failure is usually caused by some other device already claiming the IRQ the port is attempting to use.
- { The CONFIG.SYS file "DEVICE=" statements for the QCOM.SYS and QVCOM.SYS drivers should occur **after** the "DEVICE=" statement for MOUSE.SYS if a serial mouse is being used. This is because the mouse driver must take complete control of its serial port and cannot do so if QCOM/QVCOM has already claimed the port.
- { All serial ports must have parameter sets specified on the QCOM.SYS statement in CONFIG.SYS. The standard IBM drivers will install COM1 and COM2 by default. The Quatech drivers will **not** install any ports by default.
- { DOS applications may need custom configuration in order to use serial ports at nonstandard addresses. There is typically a configuration file or menu that can be used to accomplish this. Configurations typically expected by DOS applications are:

COM1: 3f8 hex, IRQ4	COM2: 2f8 hex, IRQ3
COM3: 3e8 hex, IRQ4	COM4: 2e8 hex, IRQ3
- { This driver set supports serial ports named "COM1" through "COM32". Multiport adapters should be installed such that all ports fall within this range. Ports outside this range are not usable.
- { The enhanced SERIAL.PDR spooler module is no longer supported by Quatech.
- { The device driver requires OS/2 2.11 or later.
- { At the time of release, this device driver contains no known bugs or errors. Any problems that arise will be addressed by the Quatech Technical Support Department. If a TRAP occurs and the fatal dump screen indicates that the offending code is in the "COMxx" or "QTCOM\$" driver, copy ALL of the information from the screen and be prepared to supply it to the technical support personnel. The fatal dump information can often rapidly pinpoint a problem.

Asynchronous Serial Device Driver for OS/2  
User's Manual  
Revision 3.26  
October 2006  
940-0073-326