If Windows does not install the drivers automatically, you must perform the installation manually.

In the system, in the USB controllers tab, select the device -> Properties -> Driver.

Choose to update the driver.

Then choose to search for a driver on your computer and select a driver from the list.

If you do not have FTDI directly in the manufacturer selection, select (Standard USB hubs) and on the right Model - General USB hub.

(in most cases it is not necessary to select a specific type and just enter the path to the driver as described below)

Click on install from disk and select the path about the driver from the folder papouch-usb-driver \ Old \ CDM 2.04.06 WHQL Certified.

Select the ftdibus.inf file and click OK.

The USB driver should be installed at this time.

The same procedure is for installing a serial port if it is not installed at the same time.

The only difference is for the standard com port types (if the FTDI manufacturer is not available) and the communication port model are selected in the device selection for the virtual com port.

The file used is from the same folder but for the serial port is ftdiport.inf.

Here is picture guide to installation in 8 steps:


System
Control Panel Home
Device Manager
Remote settings
System protection
Advanced system settings
See also
Security and Maintenance
Device Manager
File Action View Help
Mice and other pointing devices
Monitors
Network adapters
Other devices
Unknown device
Ports (COM & LPT)
Print queues
Printers
Processors
Software devices
Sound, video and game controllers
Storage controllers
System devices
Universal Serial Bus controllers
Etron USB 3.0 eXtensible Host Controller - 1.0 (Microsoft)
Generic USB Hub
Generic USB Hub
Intel(R) 6 Series/C200 Series Chipset Family USB Enhanced Host Controller - 1C2D
Intel(R) 6 Series/C200 Series Chipset Family USB Enhanced Host Controller - 1C26
USB Composite Device
USB Composite Device
USB Root Hub
USB Root Hub
USB Root Hub (USB 3.0)
USB Serial Converter
Update driver
Disable device
Uninstall device
Scan for hardware changes
Properties
Launches the Update Driver Wizard


Device Manager
File Action View Help
Update Drivers - USB Serial Converter
How do you want to search for drivers?
Search automatically for drivers
Windows will search your computer for the best available driver and install it on your device.
Browse my computer for drivers
Locate and install a driver manually.
Cancel


Update Drivers - USB Serial Converter
Browse for drivers on your computer
Search for drivers in this location:
ktop\papouch-usb-driver+sta
CDM 2.04.06 WHQL Certified
Browse...
Include subfolders
Let me pick from a list of available drivers on my computer
This list will show available drivers compatible with the device, and all drivers in the same category as the device.
Next
Cancel


Device Manager
File Action View Help
Mice and other pointing
Monitors
Network adapters
Other devices
Unknown device
Ports (COM & LPT)
Print queues
Printers
Processors
Software devices
Sound, video and game
Storage controllers
System devices
Universal Serial Bus con
Etron USB 3.0 eXten
Generic USB Hub
Generic USB Hub
Intel(R) 6 Series/C20
Intel(R) 6 Series/C20
USB Composite Dev
USB Composite Dev
USB Root Hub
USB Root Hub
USB Root Hub (USB
USB Serial Converte
WSD Print Provider
Update Drivers - USB Serial Converter
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Show compatible hardware
Model
USB Serial Converter Version: 2.12.28.0 [8/16/2017]
USB Serial Converter Version: 2.4.6.0 [3/13/2008]
This driver is digitally signed.
Tell me why driver signing is important
Have Disk...
Next
Cancel



See also

Security and Maintenance


System
Control Panel Home
Device Manager
Remote settings
System protection
Advanced system settings
Device Manager
File Action View Help
Mice and other pointing
Monitors
Network adapters
Other devices
Unknown device
Ports (COM & LPT)
Print queues
Printers
Processors
Software devices
Sound, video and game
Storage controllers
System devices
Universal Serial Bus con
Etron USB 3.0 eXten
Generic USB Hub
Generic USB Hub
Intel(R) 6 Series/C20
Intel(R) 6 Series/C20
USB Composite Dev
USB Composite Dev
USB Root Hub
USB Root Hub
USB Root Hub (USB
USB Serial Converte
Update Drivers - USB Serial Converter
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Show compatible hardware
Model
USB Serial Converter
This driver is digitally signed.
Tell me why driver signing is important
Have Disk...
Next
Cancel
See also
Security and Maintenance


Device Manager
File Action View Help
Mice and other pointing
Monitors
Network adapters
Other devices
Unknown device
Ports (COM & LPT)
Print queues
Printers
Processors
Software devices
Sound, video and game
Storage controllers
System devices
Universal Serial Bus con
Etron USB 3.0 eXten
Generic USB Hub
Generic USB Hub
Intel(R) 6 Series/C20
Intel(R) 6 Series/C20
USB Composite Dev
USB Composite Dev
USB Root Hub
USB Root Hub
USB Root Hub (USB
USB Serial Converte
Update Drivers - USB Serial Converter
Windows has successfully updated your drivers
Windows has finished installing the drivers for this device:
USB Serial Converter
Close